



Model 95A05-1 Hi-Fi Remote Control

DESCRIPTION

The Model 95A05-1 Hi-Fi Remote Control is used for sending IR signal to a Volume-Source Control (VSC), which in turn, sends the signal to the Hi-Fi processor. Upon receiving the IR data, the Hi-Fi processor can toggle mute, increment volume, decrement volume, change source, toggle power for the current zone, and send basic transport control commands to supported audio sources.

USING THE REMOTE CONTROL

To use the Hi-Fi2 Remote Control, point it at the VSC for the respective audio zone, and press desired button(s) as follows:

- 1) **Power:** This button turns the respective audio zone on and off.
- 2) **Mute:** This button turns mute on and off in the respective audio zone.
- 3) **Previous:** This button is used to play the previous track on supported sources.
- 4) **Next:** This button is used to play the next track on supported sources.
- 5) **Play/Pause:** This button is used to toggle between play and pause on supported sources.
- 6) **Source:** This button is used to cycle through the available audio sources.
- 7) **Volume Down:** This button decreases the volume in the respective audio zone.
- 8) **Volume Up:** This button increases the volume in the respective audio zone.

